

THRUST BALL BEARING

BOUNDARY DIMENSIONS (in mm)						
Sr No	Bearing No	d	d1	D	H	Mass (~ Kg.)
1	51107	35	37	52	12	0.085
2	51207	35	37	62	18	0.22
3	51108	40	42	60	13	0.125
4	51208	40	42	68	19	0.275
5	51109	45	47	65	14	0.14